ig(Installation Sheet ig) KSRSF313

Read these instructions before commencing installation. Please give these instructions to the owner/occupier after installation to retain for future reference/maintainence.

IP65 IK08 □ (]0.3m [€ C€ 240V~50Hz 18W

These fittings are Class II and do not need an Earth, but Earth provision is provided.

Important Information

It is recommended that these luminaires are installed and fitted by a qualified electrician ensuring the installation complies with current IEE wiring regulations & local building control. These products are designed for connection to a 240V~50Hz supply.

Any faulty, broken or damaged luminaires should be replaced immediately.

KSR will not accept responsibility for any claims arising from a poor installation.

Please Note: The limited warranty shall be deemed null and void in the following circumstances: Failure by the installer, end user or any third party to exercise caution to protect any covered product or part from outside damage, adverse temperature (normal operating ambient temperature 0°C - +30°C), humidity conditions, fluctuations in the electrical system or physical abuse as well as failure related to workmanship in the installation of the products or parts.

Important User Advice

Always switch off mains supply before servicing.

Do not use Megger or similar high voltage instruments. Due to the fact this luminaire contains electronic components that maybe damaged by high test voltages, they must be disconnected from the circuit before testing. To prevent damage to the driver, do not mix with conventional magnetic ballasts on the same electrical circuit. At the end of life the luminaire is classed as WEEE under directive 2014/30/EU and should be disposed of in accordance with local legislation.

Installation Procedure

Isolate mains supply before installation.

Unscrew and retain the four screws and remove the diffuser.

Loosen the single LED tray screw as indicated on the LED tray and lift the hinged tray to gain access to the wiring terminals.

Pass intended supply wires through grommet.

Ensure the fixing surface is flat and even.

Fix base to the wall, ceiling or besa box using adequate fixings with regard to the type of surface.

Ensure incoming cables are protected.

Terminate wiring as per Fig. 2, please note an Earth terminal is only supplied to aid the continuation of the Earth circuit.

Select LED colour required using the switch on the driver casing as per Fig. 3

Note: Never change the LED colour with the luminaire powered on as this can damage the luminaire. Connect the battery to the Emergency module.

Re-secure the LED tray.

Set up the microwave sensor as per the instructions on the reverse.

Make sure the seal is in place in the diffuser and undamaged.

Replace the diffuser re-secure using the four retained screws.

Turn on the mains supply and test luminaire.

If using an optional rim clip the rim over the fitting.

*Please note: Depending on the amount of fittings on a circuit you may have to upgrade the breaker to a 'C' or 'D' type to avoid nuisance tripping.



Navara SF (

) 18W Triple CCT Emergency Bulkhead

Available Rims: Various please visit www.ksrlighting.com for options



KSR Lighting Aftersales: 023 92 674343 E-mail: aftersales@ksrlighting.com

KSR Lighting Ltd, Unit E Hazleton Interchange, Lakesmere Road, Horndean, Hampshire, PO8 9JU

Installation Sheet)

KSRSF313

Read these instructions before commencing installation & retain them for future reference.

IP65 □ **(**€ (]^{0.3m} ≥ 240V 18W IK08

KSR Microwave On/Off Sensor Set Up Guide



Navara SF

24.08.20MAC

18W Triple CCT Emergency Bulkhead

Emergency Lighting Periodic Test Schedule

All emergency lighting should be installed and tested in accordance to EN5266-1:2011. This test schedule should remain onsite and be accessible to the relevant authorities on request.



Em No.	Luminaire Location	Luminaire Type	Start Time	Duration (Mins)	*Pass/Fail	Comments/Actions	
							Site Address:
							Test Conducted By:
							Date of Test Completion:
							Comments/Actions

× V=Pass, X=Fail, N/T=Not Tested, N/A=No Access, U/T=Uncomplete Test