Installation Sheet)KSRDL466-471

Read these instructions before commencing installation. Please give these instructions to the owner/occupier after installation to retain for future reference/maintainence.



voltage from a SELV supply is low enough that under normal conditions a person can safely come into contact with it without risk of electrical shock This fitting is Class III and is designed to be supplied from a separated/safety extra-low voltage (SELV) power source. The

Important Information

control. These products are designed for connection to a 24VDC supply ensuring the installation complies with current IEE wiring regulations & local building It is recommended that these luminaires are installed and fitted by a qualified electrician

Any faulty, broken or damaged luminaires should be replaced immediately.

KSR will not accept responsibility for any claims arising from a poor installation

Please Note: The limited warranty shall be deemed null and void in the following circumstances: Failure by the installer, end user or the electrical system or physical abuse as well as failure related to workmanship in the installation of the products or parts. any third party to exercise caution to protect any covered product or part from outside damage, humidity conditions, fluctuations in

Important User Advice

Always safely isolate the mains supply before installing, servicing or maintenance

Please ensure that a suitable maintenance schedule is performed including greasing all moving parts and protection from exposure to natural elements in the form of a non-abrasive cleaner/water repellent protection to ensure the product gives you a long lasting

Installation Procedure

- Safely isolate the mains supply Locate the areas suitable to install these luminaires
- Cut a 44mm hole in the ceiling and ensure sufficient ceiling void without infringing on joists, water pipes or electrical cables. Due to different substrates KSR recommend you test in a scrap piece of material to ensure you are happy with the cut-out size.
- suitable connector for the installation (Not Supplied). Connect the wires to from the luminaire Red (+) and Black (-) to the DC output on the chosen LED power supply using a
- with the driver (Driver not supplied) Connect the mains supply to the AC side of the chosen 24V constant voltage power supply, using the instructions supplied
- strands of wire are present. When carrying out the connection procedure always ensure all terminations are fully tightened and no loose
- Press Springs back and push luminaire into aperture
- include voltage drop calculations, it is down to the installer to calculate the cable diameters required for the installation cable Never exceed the wattage stated on the driver, driver/maximum heads recommendations below. Please note these do not lengths to avoid voltage drop.
- 10.9 Adjust tilt angle.
- Turn on mains supply and test


Driver Table

Product Code Description	Description	Max No. of lights	Dimensions (L x W x H) Class	Class
KSRDL287	20W 24V Constant Voltage Driver	5	141mm x 31mm x 22mm	=
KSRDL288	60W 24V Constant Voltage Driver	15	165mm x 42mm x 32mm	=
KSRDL292	25W 24V Dimmable Constant Voltage Driver	>8	127mm x 51.5mm x 30mm	=
KSRDL293	50W 24V Dimmable Constant Voltage Driver	8-15	183mm x 60mm x 32mm	=





Available finishes:- Black, White or Stainless Steel



Please Note These fittings must be wired In Parallel

65mm
44mm 65mm
ØRim Size ØCut out Required

light source shall be replaced.

KSR Lighting Aftersales: 023 92 674343 E-mail: aftersales@ksrlighting.com

This product contains a light source of energy efficiency class G